Lifting at front

[i]

Place inspection pit lift or garage jack at the front cross bridge for the front-axle carrier

The garage jack can use the side jacking points.



P00.60-2016-01

Lifting at rear

[i]

Place inspection pit lift or garage jack at the rear cross bridge for the rear-axle carrier

The garage jack can use the side jacking points.



P00.60-2017-01

